

HOW TO USE YOUR WHIRLPOOL DISHWASHER

Easy. Clean. Done. 🐾

1 SCRAPE & LOAD

Scrape food off dishes—**no need to pre-rinse!**

Load dishes facing the center and avoid blocking the spray arms.



Make sure the bottom spray arm can spin freely.

2 ADD DETERGENT

Use automatic dishwasher detergent only.

Place 1 pod in the detergent compartment.

Close the detergent door until it clicks.



Do NOT place the pod loose in the dishwasher.

3 SELECT CYCLE

Press POWER, then select your cycle.

Normal cycle is great for everyday use.



CYCLE GUIDE:

- Normal = Everyday dishes
- 1-Hour = Quick wash
- Heavy = Pots & pans

4 START THE DISHWASHER

Press START/RESUME and close the door **firmly until it clicks.**

You'll see lights come on to show the dishwasher is running.

You may have to

press the ▶ PLAY button TWICE for the cycle to start.



5 LET IT DO ITS JOB

The dishwasher will wash, rinse, and dry automatically.

Sit back and relax!



6 UNLOAD & ENJOY!

When the cycle is complete, the clean light will turn on.

Open the door, unload dishes (bottom rack first), and put everything away.

Enjoy your stay at Red Fish Retreat!



7 QUICK TIPS

- Don't block spray arms or overfill.
- Use HE detergent pods only—liquid can cause oversudsing.
- Scrape, don't pre-rinse. It saves water and lets the dishwasher do the work!

Thanks for being awesome guests!



8 IMPORTANT REMINDER

Sit back, enjoy a cocktail and the sunset...

Let the dishwasher do the work! 🐾



NEED HELP?

We're here if you need us! Message us anytime—we're happy to help. ❤️



QUICK START REMINDER

- 1 Scrape & load
- 2 Add detergent pod
- 3 Select cycle
- 4 Close door firmly
- 5 Press START/RESUME (play button twice if needed)

🐾 RELAX. RECHARGE. YOU'RE AT RED FISH RETREAT! 🐾

Thank You!

We appreciate you treating our home with care. Have an amazing stay! 🐾

